


EAN: 4015474190030
static.hansa.com/44410190

Ersatzteile

SP44410100



	Name	Art.-Nr.
2	Halter Chrom Ausgelaufen	59913712
2.1	Halter Chrom Ausgelaufen	59913713
2.2	Abdeckung Chrom	59913422
2.5	Deckplatte, 75x75 mm Chrom	59913326
2.6	O-Ring, d 26x2	59913423
3	Schieber für Wandstange, d 18 mm, (-2019) Ausgelaufen	59913306
3	Schieber, d 18 mm Chrom	59912781
N.I.	Brauseschlauch, L=1600 Satin	54120500