


EAN: 4015474253940  
[static.hansa.com/52600177](http://static.hansa.com/52600177)

## Ersatzteile

### SP52600177



	Name	Art.-Nr.
1	Hebel Chrom	59914629
1	Hebel Chrom	59913840
1.1	Schraube, M5x8, SW2.5	59904755
1.3	Dekorkappe Grau	59912112
2	Abdeckhülse Chrom	59912511
2.1	O-Ring, 41x3	59913215
5	Umsteller, automatisch Chrom	59910900
5.1	Druckknopf Chrom	59904828
5.2	O-Ring, d 4x1	59902331
5.3	Dichtungskit	59904791
7	Rosette, d 160 mm Chrom	59913538
7.1	Schraube, M5x65 Chrom	59904847
7.3	Gummidichtung	59913045
7.4	Führungsstück	59904846
7.5	Dichtung, 64.5x47x7 <span style="background-color: #cccccc; padding: 2px;">Ausgelaufen</span>	59912509
7.6	Ergonomischer Hebel Chrom	79901075