


EAN: 4015474162884  
[static.hansa.com/57102201](http://static.hansa.com/57102201)

## Ersatzteile

### SP57102201



	Name	Art.-Nr.
1	Hebel Chrom	59913090
1.1	Federclip	59913091
2	Zierring	59913088
2.1	O-Ring, d 40x2	59911507
3	Befestigungsschraube, M44x1 AF34	59913089
3.1	Steckschlüssel, SW34	59913092
3.2	Distanzring	59913096
4	Kartusche, 3.5 Joystick	59913051
4.1	Distanzhülse	59913093
4.2	O-Ring, d 10.10x1.60 <span style="background-color: #cccccc;">Ausgelaufen</span>	59905072
4.4	O-Ring, d 28.24x2.62 <span style="background-color: #cccccc;">Ausgelaufen</span>	59912590
4.5	O-Ring, d 28.24x2.62 <span style="background-color: #cccccc;">Ausgelaufen</span>	59912590
5.7	Befestigungssatz	59913479
5.7	Befestigungssatz <span style="background-color: #cccccc;">Ausgelaufen</span>	59913250
5.8	Anschlußschlauch, L=600, G3/8-M10x1	59913249
5.9	Anschlußschlauch, L=590, G3/8-M10x1 <span style="background-color: #cccccc;">Ausgelaufen</span>	59913166
5.10	O-Ring, d 7.65x1.78	59902337
5.11	Dichtung, 9.5x14.4x2	59912551
6	Luftsprudler, M24x1 STD HC	59913741
6.1	Schlüssel für Luftsprudler, M24x1	59913134