


EAN: 4015474263369  
[static.hansa.com/57710173](http://static.hansa.com/57710173)

## Pièces de rechange

### SP57710173



	Nom	Code
1	Levier Chrome <b>Arrêté</b>	59914018
1.1	Vis, M5x6, SW2.5	59912617
1.3	Butée de réglage Chrome	59913762
2	Chape Chrome	59914016
3	Vis, M4x1, SW34	59913365
4	Cartouche, 3.5 Eco	59912324
4	Cartouche, 3.5 Classic	59913075
4.1	Temperature adjustment limiter	59912325
4.2	Joint, d 28.24x2.62 <b>Arrête</b>	59912590
4.4	Joint, d 10.10x1.60 <b>Arrête</b>	59905072
5.1	Écrou de connexion, G3/4, AF30	59902230
5.2	Connecteur	59913400
5.3	Joint, 23.9x15.2x2	59902689
5.4	Clapet anti-retour	59905714
5.5	Mamelon de fil, G1/2xM18x1	59911384
6.1	Rosaces Chrome	59913432
6.2	Silencieux	59904792
6.3	Connecteur excentrique, G3/4xG1/2, DN15	59910254
6.4	Rosace Chrome	59912651
N.I.	Clef, SW30/34	59912108