


EAN: 4015474139749
static.hansa.com/57742101

Ersatzteile

SP57742101



	Name	Art.-Nr.
1	Hebel, 50 mm, d 7 mm Chrom	59913097
1.1	Schraube, M5x25, SW 2,5	59913099
1.4	O-Ring, d 3x1.5	59913100
1.5	Abdeckkappe Chrom	59913098
2	Abdeckkappe Chrom	59912110
3	Spann-Mutter, M37x1, AF30 Ausgelaufen	59912111
4	Kartusche, 3.5 Eco	59912324
4	Kartusche, 3.5 Classic	59913075
4.1	Temperatur-Anschlagring	59912325
4.2	O-Ring, d 28.24x2.62 Ausgelaufen	59912590
4.4	O-Ring, d 10.10x1.60 Ausgelaufen	59905072
5.1	Anschlussmutter, G3/4, AF30	59902230
5.2	Sitz, G1/2, L, WAF10	59904618
5.3	Haltering, 23.9x15.2x2	59902689
5.4	Rückschlagventil	59905714
6.1	Rosette	59913105
6.2	Schalldämpfer	59904792
6.3	Exzenter-Anschluss, G3/4xG1/2, DN15	59910254
6.4	Abdeckhülse	59913106
7	Auslauf Chrom	59913102
7.1	O-Ring, 31x1.5 Ausgelaufen	59913104
7.2	Schraube, M6x80 Ausgelaufen	59913103
8	Umsteller, automatisch Chrom	59913101
N.I.	Schlüssel, SW30/34	59912108