


EAN: 4057304017360
static.hansa.com/82609067

Ersatzteile

SP82609063



	Name	Art.-Nr.
01	Hebel Chrom	1014994V
01	Hebel Chrom	1014997V
02	Dekorkappe	59914573
03	Abdeckhülse Chrom	59914572
04	Umstellknopf Chrom	59914324
04	Griff Chrom	59914576
05	Rosette, d 170 mm Chrom	59914308
06	Umsteller, automatisch, 120°	59914655
07	Funktionseinheit	59914514