


EAN: 4057304014567
static.hansa.com/03402473

Pièces de rechange



SP03402473

	Nom	Code
01	Levier Chrome	1004279V
02	Capuchon	59914573
03	Rosace Chrome	59914572
04	Rosaces, d 72 mm, for Compact Chrome	59914667
04	Rosaces, 75x75 mm Chrome	59914213
05	Rosaces, 75x75 mm Chrome	59914214
05	Rosaces, d 72 mm Chrome	59914668
06	Croisillon d'ouverture Chrome	59914669
07	Rosace Chrome	59914671
08	Bec, L=240	59912829
09	Aérateur, M24x1 D Chrome	59911829
10	Joint, d 18x2	59913291
11	Butée de réglage Chrome	59911840
12	Vis, M6x9.5	59901609
13	Rosaces, 75x75 mm Chrome	59914209
13	Rosaces Chrome	59913450
14	Rosaces, 75x75 mm Chrome	1003885V
14	Rosaces, d 72 mm Chrome	59914672
15	Passage tablette	59914673
16	Titulaire Chrome	59912282
17	Flexible, L=1750, G1/2-M12x1 Chrome	59912281
18	Clapet anti-retour	59905714
19	Vis, M4x45	59912291