

EAN: 4015474143999  
[static.hansa.com/04010210](https://static.hansa.com/04010210)

## Pièces de rechange

### SP04010210

	Nom	Code
1	Support douche Chrome	04430100
2	Flexible, L=1250 Chrome	54120400
3	Douche Chrome <span>Arrête</span>	04310200